



名 称	KW-MF02RBA 说明书
图号	0000
版本	Rev01
日期	2022-01-19


封面 封底


















after the power is turned on, press the power button () in the standby state, and the fan enters 1 gear working mode. Press the power button () again, and the machine enters the standby state. After the fan is turned on, every time the wind speed button & is lightly touched, the wind speed will increase by I gear according to the current gear, and the highest gear will be 9 gear. When it is adjusted to 9 gear, if the wind speed button 🗣 is pressed again, the gear will continue to circulate from 1 gear. When the fan is running, every time the timing button ⁽ⁱ⁾ is lightly touched, the timing length will be increased by I hour, and the longest time will be 8 hours. When the duration of 0 is displayed, the timing 4. Shake setting When the fan is running, lightly touch the shake button \smile to turn on the fan shake head function, and the fan shake head angle is 120°. Each time the shake button \smile is lightly touched, the shake head angle decreases to 90° and 60° in turn until the shake head function is turned off. the fan is 100°. Touch the pitch button <a> again to turn off the pitch function.

校对










SOLEUSAIR BRINGS YOU A GOOD LIFE!

- A Please use the power adapter provided with the product. Before use, please make sure that the input voltage is within the voltage range required by the adapter. ⚠ Users are not allowed to disassemble and replace the internal parts of the fan at will. If there is any fault, they must contact the after-sales service department for maintenance.
- ⚠ If this product has technical improvement in the future, it will not be notified. ⚠ If the appearance and color of the product are changed, please refer to the real product. The wind of this product is strong, and it is not suitable for infants and old people to blow directly for a
- ⚠ If the power cord is damaged, it must be replaced with a special cord or a special component purchased ⚠ Children, elderly people or patients who have lost their self-care ability should use this product under adult supervision to prevent accidents.
- This product should be placed out of reach of children, and children should be taught correctly, and this product should not be used as a toy. In order to avoid electric shock, no part should be in contact with water. ⚠ Nothing can block the air inlet/outlet. ⚠ Please use this product at 0 ~ 40°C. Don't put the fan in the bathroom, humid and very high temperature
- places, so as not to damage the product. ⚠ Please keep the fan away from soft objects such as curtains and door curtains to avoid getting involved
- ⚠ When the fan is not used for a long time, please unplug the power plug to avoid shortening the product life and causing accidents or dangers when the product is in standby state for a long time. Products should be kept clean and maintained regularly. Please don't put fingers and other body parts or sundries into the air inlet/outlet, so as not to cause injury
- A Please don't put wet towels and wet rags on the product carelessly to avoid electric leakage and electric
- ↑ Take care not to touch the touch button when removing the protective shell for cleaning, so as to avoid accidents in the operation of the product. A Please put the replaced battery in the designated battery recycling location, and it is forbidden to throw the battery into the trash can.

12 / Cleaning and safety matters

- 1. Before cleaning, maintaining or moving the product, you must turn off the product and then unplug the 2. Do not clean the fan until it stops completely to avoid injury. 3. Do not immerse the power cord or the main unit in water for cleaning or rinse under the faucet. The internal parts of the fan can not touch water.
- 5. Clean the fan surface with a slightly damp cloth. 6. After cleaning, the product must be completely dried before it can be connected to the power supply for 7. If you don't use it for a long time, please put the product back in the packaging box and put it in a dry, cool and safe place.

4. Do not use detergent, wire brush, gasoline, alcohol, vinegar or other volatile corrosive liquid to clean the



	shooting		
Fault description	cause analysis	Treatment measures	
	The adapter is not plugged in	Connect the adapter power cord plug	
Machine can't work.	The power button is not pressed	Press the power button again	
Abnormal Noise	Wind leaf cracking	Please contact after-sales service	
Abhormal Noise	Motor damage	Please contact after-sales service	

14 / Environmental protection instructions


This product meets the requirements of Administrative Measures for Restricting the Use of Hazardous Substances in Electrical and Electronic Products. Ouring the warranty period, if the performance failure is caused by the quality of the product itself, the customer is requested to repair it free of charge at the designated repair point with the completed warranty card and shopping voucher. Name and content identification of toxic and harmful substances or elements The following conditions will not be repaired free of charge Loss of the warranty card and valid invoice or purchase voucher. The invoice model is inconsistent with the repair product model or altered. Sailure caused by not operating the machine according to the requirements of the manual.

	Harmful substances						
Part name	Lead (Pb)	Mercury (Hg)	Cadmium (Cd)	Hexavalent chromium (Cr(VI))	Polybrominated biphenyls (PBB)	Polybrominated diphenyl ethers (PBDE)	
Connecting wire	0	0	0	0	×	×	
Plastic items	0	0	0	0	0	0	
Power cord	0	0	0	0	×	×	
Breadboard	0	0	0	0	0	0	
Aluminium alloy	0	0	0	0	0	0	
Silicone piece	0	0	0	0	0	0	
Shell	0	0	0	0	0	0	
Accessory	0	0	0	0	0	0	
Battery	0	0	0	0	0	0	

Environmental protection life of 10 years:

It means that the harmful substances contained in this product will not leak or mutate, and the normal use of this product by users under the conditions described in the product manual will not seriously pollute the environment or cause serious damage to their personal and property. Arrow cycle flag:

It means that this product can be recycled. After the service life has expired or it can't work properly after maintenance, it should not be discarded at will. Please refer to the regular recycling channels and enterprises qualified for disposal of discarded electrical and electronic products. Please refer to the national or local regulations on disposal of used electrical and electronic products for correct disposal methods.



Place of

purchase

SOLEUS COMMERCIAL CONSULTING (SHANGHAI) CO. LTD (Trademark holder) Foshan Fangxin Network Technology Co., Ltd. After-sales service hotline: 400-8083-081 Official website: www.soleusair.com Manufacturer's address: No.304, Floor 3, Building A, No.12, Lvtian Road, North Community, Daliang Street, Shunde District, Foshan City, Guangdong Province

技术要求

- 1、105克双铜纸
- 2、折叠式(风琴折)
- 3、四色印刷 4、总尺寸: 600*280mm 5、折叠后尺寸: 100*140mm
- 6、双面印刷